



4.5" Dual SIM Smartphone

Model Number: ASP-4500Z

INSTRUCTION MANUAL

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au



N13275

Contents

Warranty Details	3
Welcome	4
General Safety Instructions	5
Product Overview	8
Getting Started	
• Before first use, Inserting the SIM card(s) and battery, Charging	10
• Buttons, Switch on/off, Turn on/off the screen	11
• Linking with your Google account	12
• SIM management	13
Operation	
• Entering your PIN, Screen operation	14
• Phone calls	17
• Contacts	22
• Messaging	23
• Applications and widgets	24
• Add and manage desktop icons	25
• Connect with computer	27
• Browser	28
• Screen compatibility, Background applications	29
• Get and install applications	30
• Uninstall applications, Play Store and calendar error messages	31
Settings	
• Wireless and networks	32
• Bluetooth, Micro SD card (TF card)	35
• Device	36
• Personalisation	38
• System	42
• Camera	43
• Radio, Downloaded files management, Special notice	44
Specifications	45
Repair and Refurbished Goods or Parts Notice	46



BAUHN®
EFFORTLESS TECHNOLOGY

4.5" Dual SIM Smartphone

Warranty Details

The product is guaranteed to be free from defects in workmanship and parts for a period of 12 months from the date of purchase. Defects that occur within this warranty period, under normal use and care, will be repaired, replaced or refunded at our discretion, solely at our option with no charge for parts and labour. The benefits conferred by this warranty are in addition to all rights and remedies in respect of the product that the consumer has under the Competition and Consumer Act 2010 and similar state and territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



After Sales Support

Telephone: 1300 886 649
Email: info@tempoaustralia.com.au

Welcome

Congratulations on choosing to buy a BAUHN[®] product.

All products brought to you by BAUHN[®] are manufactured to the highest standards of performance and safety and, as part of our philosophy of customer service and satisfaction, are backed by our comprehensive 1 Year Warranty. We hope you will enjoy using your purchase for many years to come.

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

General Safety Instructions

Read this manual thoroughly before first use and keep it in a safe place for future reference, along with the completed warranty card, purchase receipt and carton. The safety precautions enclosed herein reduce the risk of fire, electric shock and injury when correctly adhered to.

Handling and maintenance

- **Water:** Ensure that this product does not get wet, protect it from water splashes, rain, excessive humidity and sweat. Contact with water will cause the phone to short-circuit, corrode or cause electric shock. Do not use it where it can fall into water (such as near a pool, pond, bath etc.). Do not use it with wet hands. Do not immerse it in water. Do not turn it on if it is wet. Do not try to dry it in a microwave oven.
- **Handling:** To avoid damaging the phone, battery or charger, do not drop it or shake it vigorously as this may cause device or battery failure, fire or explosion.
- **Repair:** This device is a high precision electronic product. It contains no user-serviceable parts inside. Do not try to dismantle, modify or repair the device or charger yourself. Any modifications could void your warranty.

Usage environment

- **Environment:** Do not use this product where it is excessively hot, cold, dusty or humid, or where it is exposed to strong magnetic fields or long periods of sunshine. Exposure to very low or very high temperatures may cause device or battery failure, fire or explosion.
- **Heat sources:** Do not leave the product near any heat sources, stoves, ovens or other appliances (including amplifiers) that produce heat.
- **Interference:** Do not use the phone near other electronic devices that use radio frequency signals. Avoid using it within a 15cm range of a pacemaker (if you have a pacemaker, do not carry the phone in a breast pocket).

Safety

- **Road safety:** Obey all local laws and regulations on the use of mobile devices in the area where you drive. Give full attention to driving and the road. Keep your hands free to operate the vehicle at all times; use hands-free operation or an earpiece if phone usage is required.
- **Health facilities:** Observe relevant rules or regulations regarding mobile phone use in health facilities. Turn off the phone in the vicinity of medical devices and wherever directed to do so by posted signs. Mobile phone radiation may interfere with pacemakers, hearing aids and other medical equipment.
- **Aircraft:** Turn off the smartphone when boarding an airplane in order to avoid interference with aircraft radio signals.
- **Magnetic equipment:** Stay away from magnetic equipment to avoid the risk of interfering with or erasing the information stored on the device.
- **Volume:** Always select the appropriate volume when using the music or video function. The volume should not be too loud when using earphones.
- **Explosive environments:** Turn off the phone in blasting areas and in any potentially explosive environment (such as at a petrol station or other refuelling points).
- **Back-up:** To avoid loss of data, we recommend always backing up any important information, especially before upgrading the hardware. We assume no liability for any damage and/or data loss due to lack of back-up.
- **Flashlight:** Do not use the flashlight close to the eyes of people or pets.

Accessories

- **Accessories:** Only use the device with the Micro USB cable and battery charger supplied. Use of other accessories not recommended in this manual may cause damage to the unit and void your warranty.
- **Battery charger:** Only use the charger provided. Do not use the phone while it is charging. Do not drop or cause an impact to the charger.

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

General Safety Instructions (Cont.)

- **Battery handling:** Do not expose the battery to high temperatures. Take care when handling a charged battery, particularly when placing it inside your pocket, purse or other container with metal objects.
- **Power cord:** Do not bend or damage the cable of the battery charger.
- **Damage:** Do not use the charger if the cable or plug are damaged. In case of damage, contact the after sales support line for advice.
- **Disconnect:** Grip the plug when disconnecting the charger; do not pull on the cord.
- **Memory card:** Always handle the phone's memory card(s) with care. Protect the card(s) from static electricity and strong shocks.

Usage conditions and restrictions

- **Packaging:** Plastic packaging materials can present a suffocation hazard for young children and babies. Keep all packaging materials out of children's reach to ensure they do not play with these.
- **Personal usage:** Do not use this product for anything other than its intended purpose, and only use it as described in this manual.
- **Restricted usage:** The equipment is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the equipment by a person responsible for their safety.
- **Children:** This phone is not a toy. Keep the phone, battery and charger away from young children. Supervise young children when the phone is going to be used by or near young children.
- **Cleaning:** Clean the housing of the device lightly with a dry cotton cloth. Do not use alcohol, thinners, benzene or any other chemical cleaning solutions.
- **Lost phone:** We recommend you inform your telecommunications service provider to block your SIM card(s) when your phone is lost. You may also want to ask them to block the phone's IMEI number(s), these are printed on a label inside the phone underneath the battery. (Alternatively, the number(s) will be included on a label with the packaging.) Please note down these numbers so you have them handy in case your phone is lost.
- **Disposal:** When discarding this device, observe local regulations and dispose of it appropriately for recycling. Never dispose of the battery in a fire. Contact your local authorities for advice on facilities.
- **Noncompliance:** We accept no liability for any damage caused by noncompliance with these instructions or any other improper use or mishandling.

Abbreviations / Terminology

Wi-Fi	Wireless Fidelity
BT	Bluetooth
TF card	Trans Flash (also named Micro SD)
SIM card	Mobile service card

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Product Overview




- 1 Power Button
- 2 Micro USB Socket
- 3 Options / Settings
- 4 Home
- 5 Back / Return
- 6 Front Camera
- 7 Light Sensors

- 8 Earpiece
- 9 3.5mm Hands Free Socket
- 10 Rear Camera
- 11 Flash
- 12 Micro SD Card Slot
- 13 Battery Bay
- 14 Loud Speaker

After Sales Support

Telephone: 1300 886 649
Email: info@tempoaustralia.com.au

Product Overview (Cont.)



- 15 SIM 1 Bay (WCDMA/GSM)
- 16 SIM 2 Bay (GSM)
- 17 Cover Removal Groove
- 18 Microphone
- 19 Volume Up/Down
- 20 Search
- 21 Notification Bar

Getting Started

Before first use

- Unpack the product but keep all packaging materials until you have made sure your new 3G Smartphone is undamaged and in good working order. Plastic wrapping can be a suffocation hazard for babies and young children, so ensure all packaging materials are out of their reach.
- Unwind the USB cable and battery charging adaptor and inspect them for damage. Do not use the cables or the charger if any part is damaged. In case of damage, contact our after sales support line for advice on examination, repair or return of the damaged product
- Read this manual to familiarise yourself with all the features and operating principles of your new 3G Smartphone. Pay particular attention to the safety instructions on the previous pages.

Inserting the SIM card(s) and battery

- Place your finger in the small recess in the corner of the mobile phone and with your fingernail, carefully prise it open and lift off the back cover.
- If the battery is in place, remove it.
- Insert your SIM card(s) into the dedicated bays. Bay number (1) supports GSM and WCDMA; bay number (2) supports GSM only. If required, insert a micro SD card into its dedicated space.
- Once the SIM and SD cards are securely in place, insert the battery (supplied) into the phone, making sure to align the pins with the contacts.
- Reinstall the back cover. It will lock into place.

NOTE: Some SIM cards require a PIN number to be entered before use (see page 14 for details). This PIN may be printed on the SIM card packaging, or you may have to contact your service provider for the number.

Charging

The battery has been partially charged at the factory. To perform all functions, we recommend you fully recharge it as follows:

- **To charge the device with the battery charger**, plug the large end of the USB cable into the charging adaptor and the smaller end into the micro USB port on the 3G Smartphone. Plug the charger into your mains power supply.
- **To charge the device using the USB cable and computer**, plug the large end of the USB cable into a USB port on your computer and the smaller end into the micro USB port on the 3G Smartphone. Ensure your computer is turned on.

After Sales Support

Telephone: 1300 886 649
Email: info@tempoaustralia.com.au

Getting Started (Cont.)

- When the phone indicates a full charge (the battery status icon is located in the top right corner of the display), disconnect the charger or USB cable.
- Follow one of these charging procedures whenever your 3G Smartphone indicates a low battery charge.

Switch on/off

Power button

- Long press to turn on.
- When in power-on state, press to turn on or off the screen.
- When in power-on state, long press to display the power off menu.

NOTE: If phone becomes unresponsive, remove and reinsert the battery

Switch on

- While in power-off state, press and hold the power button for 2 seconds and the device will start up.

Switch off

- Press and hold the power button for 2 seconds: an options list will appear on the screen.
- Choose to switch off the device.

Turn on/off the screen

The screen will automatically turn off when in idle time

- After a period of inactivity the screen will automatically turn off to save battery power. This can be set using the "Sleep" setting from the display menu in the device settings menu.
- If after a long time in sleep state the screen does not turn on, remove then reinsert the battery. Then press the power button to turn on again.

Turn on the screen

- If the screen is off, press the power button to turn it back on.

Volume

- To adjust the ringer volume, press the Volume Up or Volume Down buttons on the right side of the 3G Smartphone to the desired level. While adjusting the ringer volume, a window will appear on the screen displaying the volume levels.

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Getting Started (Cont.)

Linking with your Google account

When you turn on the phone for the first time, you can sign in to your Google Account so you can synchronise Gmail/Google Mail, Calendar and Contacts between your phone and the web. You also need to sign into a Google Account to use Google Apps such as Google Talk™ and Play Store.

- On your phone go to “Settings” and tap ‘Add Account’>‘Google’>‘Existing’.
- Tap “Sign in”, enter your user name and password and then tap “Sign in”. After signing in, all emails, contacts, and calendar events on your Google Account will automatically synchronise with your phone.

NOTE: Tap “Create” if you do not have a Google Account yet.

Google Account password

If you cannot remember your Google Account password, follow the steps below to retrieve it:

- On your computer, open your browser and go to <http://google.com/accounts>.
- On the right side of the page, tap “I cannot access my account”.
- In the “Please select your issue” section, select “I forgot my password”.
- Tap “Reset your password now”, and then follow the procedure on how to recover your password.

NOTE: See pages 34-37 for more on using your phone to access Gmail, Google Calendar, Play Store etc.

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Getting Started (Cont.)

SIM management

This 3G Smartphone can be used with two SIM cards: SIM1 and SIM2. Bay number (1) supports GSM and WCDMA; bay number (2) supports GSM only. When you have two SIM cards inserted, you can choose to use either SIM1 or SIM2, or both of them. Unless you have determined use of one particular SIM card as your default card in the settings, you will be prompted to choose an appropriate SIM card every time you want to make a call, send a message or connect to the internet.

SIM Information


Tap the check box to choose enable or disable a SIM card, or tap a SIM card to change its information.

Default SIM

You could choose the default SIM card for your voice calls, video calls, messages or connection.

General settings

You could change roaming settings or associate contacts with a specific SIM.



After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au


Operation

Entering your PIN

If you want to use a SIM card that is preset with a PIN (personal identification number), you will have to enter the PIN to proceed. Just follow the prompts to enter the SIM PIN and then tap "OK".

Screen operation

Click / Short Press	When using the on-screen keyboard, opening an application or selecting items
Long Press	Press and hold for several seconds on an item (such as a text box or web page link) to display the action or submenu for an item, if available.
Slide or Rapid Slide	Sliding or fast sliding means vertical or horizontal drag action.
Drag	When dragging, you must hold the icon with your finger and keep pressure until it reaches destination.
Display Rotation	For most of the screens, the content will change between landscape and portrait mode, according to the device orientation.



Unlocking the main screen

- Press and hold on the lock icon and several options will pop up. Drag the lock to the right side to unlock the screen; drag it to the left side to enter camera function.
- After unlocking the screen, you will see the last item you had open or the main screen, which has five windows or pages. You can view the pages by dragging your finger left and right across the screen.
- To return quickly to the main screen, press the Home button.

After Sales Support

Telephone: 1300 886 649


Email: info@tempoaustralia.com.au

Operation (Cont.)

Screen buttons

There are four buttons at the bottom of the screen. No matter what functions you are using, you can return to the last page or main screen by using these buttons.

Button	Name	Description
	Back	Go to the last page (even in another application). When returned to the main screen, you cannot go to the last page again.
	Home	One key to return to the main page (the middle page among the five pages).
	Recent applications	Display a list of recently used applications / background applications.
	Search	Search for applications on your phone

Icons	Description
	From left to right: Wi-Fi Signal Status, SIM Signal Status, Battery Status, Current Time (depends on current applications).
	Click to display a list of all applications and widgets.
	Click to search for a file or application on the 3G Smartphone, or to search the internet.

After Sales Support

Telephone: 1300 886 649
Email: info@tempoaustralia.com.au

Operation (Cont.)

Notifications

The notification bar shows you at a quick glance the status of your phone. It can be expanded to show more information and quick access to settings.

Notification icons inform you of the receipt of new messages, calendar events, set alarms and ongoing settings for things such as active call forwarding or the current call status. Below is a description of their meanings. Click on the column box to open the notification list.

Expanding and closing the notifications panel

- To expand the notifications bar to see all the options, place your finger on the notification bar then swipe/drag in a downward motion.
- To hide the notification bar, press the back button.


	File being downloaded		Bluetooth
	Play Store		No SD card
	Connected with PC		Wi-Fi connected
	GSM signal		Common notification
	Alarm clock on		Micro SD space not enough
	Uploading/downloading		To-do events
	Download finished		Charging
	Data Synchronisation		3G

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Operation (Cont.)



Phone calls

Making a call

You can make a phone call a number of different ways.

Calling using the dialler



- Tap  (call/phone) at the bottom of the screen to enter the dialler screen.
- In dialler mode, when you input a number, you have two options to make a call.
 1. Directly tap “Call” on the keyboard and then choose which SIM card you want to use (if you have two SIM cards inserted).
 2. Slide to the right to choose the number in your call history.

NOTE: * If you have only one SIM card inserted, you cannot use another SIM card to make a call. When one SIM card is used for a call, the other is temporarily unavailable.

* See page 21 for call setting options.

Calling a phone number in a text message

While viewing a text message, you can place a call to a number that is in the body of the message.

- Tap the message with the phone number.
- Tap the number you want to call on the “Select action” screen. The dialler screen then opens with the phone number automatically filled in and ready to be dialled.
- To place the call, tap “Call” (and select the SIM card you want to use, if appropriate).

Calling a phone number in contacts

- To call a number from your contacts, enter the contacts list and select the contact, then tap the “Call” icon behind the number you want to call.

Making an emergency call

- Dial the appropriate emergency number (000 or 112 in Australia), and then tap “Call”.
- If your phone is locked with a pass code, you may still be able to make an emergency call. On the “Enter pass code” screen, tap “Emergency call”, then enter the emergency number and tap the red button.

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Operation (Cont.)

Incoming phone calls

- **Receiving a phone call from a contact:** When you receive a phone call from a contact, the incoming call screen appears, displaying the caller ID icon, name and phone number of the calling party.
- **When you receive a phone call from someone else** (whose contact details are not stored in your contacts), only the default caller ID icon and phone number will appear on the incoming call screen.

Answering a call

Slide the “Call” icon across the screen to answer an incoming call.

Rejecting a call

Slide to the “End call” icon to reject.


Muting the ring sound

To mute the ring sound without rejecting the call, press the Volume Down button or Power button. You can also mute the ring sound by first tapping “Menu”, then “Mute”.

In-call options

When a call is in progress, you can still operate key options. Tap the available buttons to put a call on hold, dial another contact for a phone conference, mute the phone microphone, and more.

NOTE: When the phone is dialling, only the “End call” and “Speaker on” icons are available.



After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Operation (Cont.)

Muting the microphone

- Tap “Mute” to turn the microphone on or off. When the microphone is turned off, the “Mute” icon appears in the status bar.

Putting a call on hold

- Tap “Hold” to put the call on hold. When you put a call on hold, the “Hold call” icon appears in the status bar. Tap “Unhold” to resume the call.

Turning the speakerphone on/off

- When you are on a call, tap “Speaker” to toggle between turning the speakerphone on or off. The “Speakerphone” icon appears in the status bar when the speakerphone is on.
- **WARNING!** Protect your hearing! Do not hold the phone against your ear when the loudspeaker is turned on.

Ending a call


You have two options to end a call:

- Tap “End call”.
- If you are using a wired headset, press and hold the button to end the call.

Video calls

Use this function when you want to see as well as hear the person you are phoning, if that person’s mobile phone supports this function.

NOTE: Not all mobile phones and networks support video calling. Contact your service provider for details. Video calling may incur extra charges.



After Sales Support


Telephone: 1300 886 649
Email: info@tempoaustralia.com.au

Operation (Cont.)

Call log tab

Enter the dial number and slide to the right to the call log. Then select to:

- Tap the name or number in the list to phone the contact.
- Tap the contact icon of a name or number in the list to display the options menu where you can choose from the following options: "View contact information" (if the number is stored in your contacts list), "Edit number before call", "Send text message", or "Remove from call log".



Phone settings

You can adjust the phone settings of your phone such as your voice mail number, or enable additional call services from your network service provider.

To open the phone settings menu, select SIM1 or SIM2 as appropriate, then tap "Home" > "Menu" and then tap "Settings" > "Call settings".

Options	Description
Fixed dialling numbers	Restrict outgoing calls to a fixed set of numbers. To enable this feature you must know your SIM card's PIN 2 code.
Voice mail	Specify another voice mail number aside from the voice mail number on your SIM card.
Auto answer	1 ring, 2 ring, 3 ring, Never Answer (default)
Call forwarding	Select how you want your phone to handle calls when busy, unanswered and unreachable. You can also set call forwarding options for all incoming calls.
Call barring	Select barring outgoing or incoming calls. Contact your network service provider(s) to activate this function.
Additional call settings	Enable or disable operator services such as caller ID and call waiting.

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Operation (Cont.)

Call settings

Voice call

Select this option to change settings for your voice mail service and number, voice call forwarding, voice call barring, phone number and call waiting settings.

Video call

Select this option to change your video call settings such as set a picture to display when the camera not in use, size of peer video and local video, etc.

Internet call

Select this option to log into an Internet call account.

Other settings

Select this option to manage fixed dialling numbers, call cost information, mobile broadcast settings and minute reminder.

Airplane mode

To enable/disable airplane mode, choose one of the following options:

- Press "Home" > "Menu", then tap "Settings" > "Wireless controls".
- Press and hold the Power button and then tap "Airplane mode".
- In the notification bar, tap the "Airplane mode" shortcut to turn airplane mode on or off.

NOTE: When you disable airplane mode, the phone function is turned back on and the previous Bluetooth and Wi-Fi states are restored.

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Operation (Cont.)

Contacts

The contacts application lets you manage your phone, messaging and email communications with the contacts in your contacts list. If you are synchronising contacts with your Google account via your PC tools, any contacts stored in those accounts will be displayed.

Contacts list

Adding a new contact

- On the Contacts list screen, press the  button, then tap "Create contact".
- Enter the contact information in the fields provided.
- Scroll to the bottom of the screen and tap "Save".

Searching for a contact

- Press the  button to enter the search menu, a search bar will appear at the top of the Contacts list screen.
- Enter the first few letters of the first or last name of the contact you are searching, matching contacts will be displayed.

NOTE: If the list of matching contacts is long, tap to hide the on-screen keyboard to view more results.


Deleting a contact

- On the Contacts list screen, press "Menu" and then tap "Delete contact".
- On the Delete screen, you can select "Multiple choice", or "Mark all".
- **WARNING:** This operation will delete the contact. Take care when using it.

Display options

Choose this setting to customise your display options, including default and Gmail account display options.

NOTE: After synchronising contacts with your Google account, add the contact to the phone and select "All other contacts" in your Gmail account display options to display the contacts in the list.




After Sales Support

Telephone: 1300 886 649
Email: info@tempoaustralia.com.au

Operation (Cont.)

Messaging

Messaging lets you compose and send text (SMS) and multimedia messages (MMS) to other mobile phones.



Creating and sending SMS and MMS messages

- Any text (SMS) messages you compose that contain up to 160 characters will be delivered as one message. If your message contains more than 160 characters, it will still be delivered as one but it will count as more than one message. Your service provider may charge you extra for such linked (concatenated) messages.
- Multimedia (MMS) messages can contain text and a picture, a recorded voice, an audio or video file or a picture slide show.
- To create and send a text message**, tap "Create" on the All messages screen and enter the phone number of the message recipient in the To field on the Compose screen. Any matching contacts will appear on the screen. Tap a recipient or continue entering the recipient's phone number. Tap the text box that contains the text "Type message", and then start composing your message. When done, tap "Send" to send the message.

NOTE: As you compose the message, a counter in the top right corner of the text box will keep track of the number of characters. Once you go over 160 characters, a new message is created but automatically linked into one when received.

NOTE: To receive delivery reports and notifications when a text message is received, press "Menu" and then tap "Settings" on the All threads screen. In the SMS settings section, select the "Delivery reports" check box.

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Operation (Cont.)

Applications and widgets

Enter applications



Click  to enter the list of all applications and widgets.
Click on the APPS tab in the top left corner.

- This window will display a list of the applications.
- As you install more applications, the first page will fill up and the application icons will automatically spread onto other pages.
- Swipe left and right to see the other pages.

After Sales Support

Telephone: 1300 886 649


Email: info@tempoaustralia.com.au

Operation (Cont.)

Add and manage desktop icons


Add desktop icons

At the application list or widget list, long press any application or widget and the device will shift into desktop, then drag the icon to any place on the desktop.



Desktop shortcuts management

To create a folder on the main screens, just drag and overlay any icon onto another icon, then release. A new folder will be created containing the two applications. It will appear as a black circle with small icons of your apps on top.




After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Operation (Cont.)


Then you can view the folder contents by clicking on the folder icon and it will display as pictured below.



You can change the icon positions inside the folder by long pressing them, then dragging to the new position.

If you want to remove an icon from the folder, long press the icon and drag to outside the folder.

To change the folder name, click on the folder, then tap “Unnamed folder”. A keyboard will appear. Type the new name, then tap “Enter” to apply it.




After Sales Support

Telephone: 1300 886 649
Email: info@tempoaustralia.com.au


Operation (Cont.)

Gallery	Choose from the pictures stored on your 3G Smartphone camera gallery or any pictures downloaded onto the device.
Wallpaper	Choose from the default wallpapers.
Live Wallpaper	Choose a moving wallpaper



Connect with computer

Connect the device with a computer using a USB cable. When connected with a computer, the screen will show as below.



- Tap "Turn on USB storage" to enable your computer to access the internal storage area and SD card of the 3G Smartphone. The green Android Robot image should turn orange and the button will change to display "Turn off USB storage".

NOTE: If the message above does not appear when you connect the 3G Smartphone to your computer using a USB cable, or the device does not appear on your computer after pressing the "Turn on USB Storage" button, try the following.

- Check the notifications bar for messages about USB connection
- Check and ensure that you have turned the 3G Smartphone on. Check and ensure that your computer is turned on.
- Unplug the USB cable, then reconnect it to the same USB port.
- If your computer has USB ports on the rear, try connecting to one.
- Try a different USB cable.

After Sales Support


Telephone: 1300 886 649
Email: info@tempoaustralia.com.au

Operation (Cont.)

Browser



Tap  to open the browser.



Tap  to open a new browser window.



Tap  to close the current browser window.

When the internet signal is poor and the web page does not load, tap “Refresh” in the menu to try loading the web page again. There are many useful advanced options in “Settings”.

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Operations (Cont.)

Screen compatibility

When the device is installed with programs designed for small screen and cannot show in full screen, a screen zoom menu will pop up. You must confirm it to open those programs.

Background applications

Tap the “background applications” (recent applications) on-screen button to show all programs running in the background. Tap an item to re-open it.

Drag the items to the left or right to close and remove the application from the list.

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au


Operations (Cont.)

Get and install applications

There are two ways to get applications software: download through this device or copy from a computer.

Option 1: Download using a “Market” or “Store” application

Download applications software using applications such as Google’s “Play Store”. Below are photos showing the process of downloading “Angry birds” from “Play Store”.



After downloading, the application will automatically install the software.

NOTE: Some applications may not be compatible due to hardware requirements or geographic location limitations of the application.

Option 2: Copy installation file from computer

Copy an application install file (APK) from a computer to the storage of the 3G Smartphone, then find and install them using “File manager”. Tap on the file to install it.

After Sales Support

Telephone: 1300 886 649
Email: info@tempoaustralia.com.au

Operations (Cont.)

Uninstall applications



- Open the applications window and tap , then tap on “Apps” from the menu on the left.
- Use the tabs at the top and scroll up and down through the list of applications until you find the application you wish to uninstall.
- Click on the application, then an App info page will appear.
- Click on the Uninstall button and the application will be removed.

Play Store and Calendar error messages

Occasionally when linking a new Google account to your 3G Smartphone, you may receive various error messages such as “...error (-101)...” in the Play Store, or your Calendar appointments and events may not appear.

To fix this issue and re-synchronise the 3G Smartphone with your Google account, please follow the steps below.




1. Open the applications window and tap , then tap on “Apps” from the menu on the left.
2. In the window on the right-hand side, tap the “All” tab at the top.
3. Scroll up and down through the list of applications until you find “Google. Services. Framework” and click on it.
4. Tap the “Clear data” icon.
5. Click on “Yes”.
6. Press and hold the Power button for 2 seconds.
7. Tap “Yes” to agree to turn off the 3G Smartphone.
8. Once the phone has finished shutting down, turn the phone back on.
9. Open the “Play Store” app and wait for the images to load. Once they have finished loading, press the Back button.
10. Wait for 30 seconds then reopen ‘Play Store’ app.
11. You may now open “Calendar” and check your entries are there, or open “Play Store” and download the application you that was giving the error message.

After Sales Support

Telephone: 1300 886 649
Email: info@tempoaustralia.com.au


Settings

The setting function on this 3G Smartphone is like that on a computer control panel. You can access the settings page from the notifications bar or “Setting” icon in the applications list.



Wireless and networks

The “Mobile Networks” section is located under the “More” option.



- To activate data using your SIM card select “Data connection”.
- The remaining settings should be left with default values unless your local service provider advises you otherwise.


After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au


Settings (Cont.)

- Tap “Wi-Fi” to open the Wi-Fi function.
- To the right of the “Wi-Fi” label is the button to enable and disable Wi-Fi.
- Press the On/Off button to turn the Wi-Fi function on or off
- Click on the network you wish to connect to.




Connecting Wi-Fi

When the Wi-Fi network is not protected, it will connect with the device automatically. For information security reasons, be careful using unprotected Wi-Fi sources. When you click on a protected Wi-Fi, a window will pop up to input a password.



Settings (Cont.)

There are more useful advanced Wi-Fi settings when you choose to “Show advanced options”.



Settings (Cont.)

Bluetooth

Enable or disable bluetooth



1. Tap “Settings” at the main menu or applications list.
2. In the “Wireless & networks” menu, tap “Bluetooth”.
3. Tap the On/Off button in the menu on the left to turn Bluetooth on or off.

Change Bluetooth device name

By default, the Bluetooth device will have a name. To make your devices more easily identifiable, you can rename it as follows.

1. Go to “Settings” > “Wireless & networks” and make sure Bluetooth is on.
2. Choose “Bluetooth”.
3. Tap the options button and choose to “Rename phone”.
4. Input the new name.

Pair with other Bluetooth device

1. Tap “Search for devices”, the device will scan for all available Bluetooth devices. If it cannot find the one you want, check if the other device Bluetooth is on.
2. Tap a Bluetooth ID to pair. If it is password protected, input the password at both devices.

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au


Settings (Cont.)

Device

Sound


Set all sound options here.

Click on "Volumes" to change the volume levels for multimedia players and applications, and also for notifications and alarms.



Display

You can set brightness, wallpaper, auto-rotate and font size options.



After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Settings (Cont.)

Storage

Internal storage: space for installation of applications (APK software)

Phone Storage: space for file storage

External SD: storage space on the removable SD card
(if inserted)




Battery

Show battery balance and consumption.

Applications

Here you can manage applications, such as uninstall them or clear application data.



After Sales Support

Telephone: 1300 886 649


Email: info@tempoaustralia.com.au

Settings (Cont.)

Personalisation

Location services

Allows you to enable or disable the various location services such as GPS.



After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au


Settings (Cont.)

Security

The security menu contains many useful options for securing your 3G Smartphone and data.

Screen lock: Change or set a protection method for locking the screen.

Owner info: Enter text that will be displayed on the lock screen. This is a message that others can see without having to unlock the phone.



Encrypt phone:

Apply encryption to all data on the 3G Smartphone. Also requires you to enter a PIN or password to use your phone each time you turn it on.

WARNING: Data cannot be recovered if you forget the PIN or password you set!

Unknown sources: Enable this if you wish to install applications (APK files) that are not from the "Play Store".

NOTE: If you forget the screen lock password, PIN or pattern, you must perform a firmware reset on the device. Passwords cannot be recovered.

After Sales Support


Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Settings (Cont.)

Language and input


In this area you can change the system language and change settings for the keyboard.



Keyboard

Some applications can open the keyboard automatically; others require you to click in an input field/area first.

You can hide the keyboard by holding down the Back button.



After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Settings (Cont.)

Text selection - Copy, Share, Find

- Press and hold on one of the words you wish to select. The word will highlight in blue and a blue tab will appear at both ends.
- Press and drag the blue tabs to highlight the text you wish to select.
- Choose the task you wish to perform from the menu that appears at the top of the screen.

Text selection - Paste

- Once you have used the above method to copy text to the clipboard, press and hold on a field in an application or area of a document where you wish to input the copied text.
- A blue tab will appear, drag it to the position you want the text inserted, then click 'Paste'.

Other operations

To input capital letters:

- Press the Shift  button or keep pressing on Shift  while inputting letters.
- To switch to capital letters:
- Press and hold the shift  button while in lower case mode, the icon will change into . Press again to switch back to lower case mode.
- Figures and numbers:
- Press the “?123” button. You can then press the “-|_” button for more choices.

Frequently used symbols:

- Press and hold a symbol button to enter the alternate symbol displayed in grey above it.
- Press Shift  and click the special symbol which is shown in grey at the corner of any letters to input the symbol.


Mouse/trackpad

This allows you to adjust the pointer speed of any attached mouse or trackpad device, such as a Bluetooth mouse.

Settings (Cont.)

Backup and reset

Reset to factory settings: When some applications or the phone itself do work properly, you can use this function to return the 3G Smartphone to factory default settings. But you will lose all user installed applications and data. It is therefore important that you back up important data first.



Accounts and sync

This allows you to add an account to the 3G Smartphone and enable or disable the synchronisation settings for each, such as mail service.

You can also remove accounts by tapping on them, then tap on the menu button in the top right and select "Remove account".

System

Date and time

Contains options for setting the time zone, date and time.

Accessibility

Contains settings for easy use of applications and services (if installed).

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Settings (Cont.)

Development

NOTE: This section contains settings for advanced Android users only, such as application developers. By default all settings in this area are set to "Off".

About

Displays some information about the device.


Camera

The camera has photo-taking and video-recording functions. There are two cameras on the phone.

You can find your camera photos and video footage at > Applications > Gallery, or see camera videos and all other video files at > Applications > Video Player.

Click  to take photos.

- To take a photo: click the blue circle.
- To view captured photos: click on the small photo preview icon.
- To exit: press the Main Screen button.



Icon	Name	Description
	Mode	Shift between camera, video recorder and panorama camera
	Switch cameras	Shift between rear and front camera
	Zoom	Zoom in or out
	Settings	Other settings

Downloaded files management

When downloading files, you can check download status, view, reopen or delete them using "Download management".

Manage downloaded files

- Applications > Downloaded files 
- Tap any one to open it.
- Choose any file you want to share with others, then tap "Sharing" , then choose a way to share.
- Choose any file you want to delete by tapping .
- Click "By size" or "By date" to array the files.

After Sales Support

Telephone: 1300 886 649
Email: info@tempoaustralia.com.au

Settings (Cont.)

Radio

To use your 3G Smartphone to listen to the radio, first insert the earphones, then tap "FM Radio".

Selectable channel



- Tap "OK" to select the  or  icon to scan through the frequency band or fine-tune a channel.

Adjust the volume

- Tap "Menu", then select "Mute" to mute the sound; select "Mute" again to restore the sound.
- With the earphones disconnected, tap "Menu", then select "Speaker" to listen to the radio volume through the external speaker.

Scan and save

- Press the Setting button and select "Scan & save".
- If you tap "OK", all presets will be removed and the radio will scan for available channels.

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au

Specifications

Processor and Memory	
CPU	Qualcomm MSM8225 1GHz Dual Core
OS	Android 4.1
Display	4.5" qHD IPS LCD Screen
Resolution	960 x 540 resolution
Internal memory	Built-in 4GB
RAM	512MB
Features	
Touchscreen	Capacitive multi-touch screen
Battery	Built-in 2000mAh Li-Polymer battery
WiFi	IEEE 802.11
Bluetooth	Bluetooth 3.0
SIM	Dual SIM / Standby
2G / 3G module	2G: GPRS / EDGE, 3G: WCDMA
Frequency	WCDMA (850/2100) MHz GSM (850/900/1800/1900) MHz
GPS	Built-in GPS module
G sensor	Supports rotation sensor
Cameras	Front: 0.3MP, rear: 5.0MP
Radio	FM Radio
Micro SD	Supports up to 32GB
Microphone	Built-in microphone
USB	Micro USB
Card reader	Supports Micro SD card up to 32GB
I/O Ports	1 x Micro USB 1 x 3.5mm Headphone jack

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au



BAUHN®
EFFORTLESS TECHNOLOGY

4.5" Dual SIM Smartphone

Repair and Refurbished Goods or Parts Notice

Unfortunately, from time to time, faulty products are manufactured which need to be returned to the supplier for repair.

Please be aware that if your product is capable of retaining user-generated data (such as files stored on a computer hard drive, telephone numbers stored on a mobile telephone, songs stored on a portable media player, games saved on a games console or files stored on a USB memory stick) during the process of repair, some or all of your stored data may be lost. **We recommend you save this data elsewhere prior to sending the product for repair.**

You should also be aware that rather than repairing goods, we may replace them with refurbished goods of the same type or use refurbished parts in the repair process.

Please be assured though, refurbished parts or replacements are only used where they meet ALDI's stringent quality specifications.

If at any time you feel your repair is being handled unsatisfactorily, you may escalate your complaint. Please telephone us on 1300 886 649 or write to us at:

Tempo (Aust) Pty Ltd ABN 70 106 100 252
PO BOX 6056 Frenchs Forest, Sydney, Australia NSW 2086
Telephone: 1300 886 649 (Aust) - Fax: (02) 9975 2688
Tempo Help Desk: 1300 886 649 (Aust)
(Operating Hours: Mon-Fri 08:30am to 06:00pm EST)
Email: info@tempoaustralia.com.au



After Sales Support

Telephone: 1300 886 649
Email: info@tempoaustralia.com.au

After Sales Support

Telephone: 1300 886 649

Email: info@tempoaustralia.com.au